

BMS Kia Stinger/Genesis G70 3.3L Oil Catch Can Install Guide

Last updated 8/08/2025

Use subject to terms and conditions posted at <https://burgertuning.com/pages/terms>

THIS PART IS LEGAL FOR USE ONLY IN COMPETITION RACING VEHICLES AS DEFINED UNDER CALIFORNIA LAW AND IS NOT LEGAL FOR USE IN ANY OTHER MOTOR VEHICLE. California law defines a "racing vehicle" as "a competition vehicle not used on public highways." (Calif. Health & Safety Code 39048) This part may only be used on competition racing vehicles operated exclusively on a closed course in conjunction with a sanctioned racing event. Competition-only motor vehicles may not be driven to a racing event on a public highway and must be transported on a trailer or other carrier. USE OF THIS PART IN ANY OTHER VEHICLE MAY SUBJECT YOU TO FINES AND PENALTIES FOR VIOLATION OF FEDERAL AND/OR STATE LAW, WILL VOID YOUR WARRANTY FROM BURGER MOTORSPORTS, INC, AND CAN VOID YOUR VEHICLE'S WARRANTY. It is your responsibility to comply with all applicable federal and state laws relating to the use of this part, and Burger Motorsports, INC hereby disclaims any liability resulting from the failure to use this part in compliance with all applicable federal and state laws.



Remove the PCV hose by pinching the clamp and pulling the hose off. Next remove the 14mm bracket bolt. The smaller hole below it will be used as an alignment hole for the lower bracket screw. Also note that this hole is not threaded.



Assemble the bracket. 5mm Allen (hex) shorter screw goes into #1 as a dowel. Longer screw goes into #2 but don't tighten yet.



Use the factory 14mm bolt to attach the bracket.



Now put the can all the way in and tighten the bracket hoop screw with a 5mm Allen (hex) wrench.



Now put the can in and tighten the bracket hoop screw with a 5mm Allen (hex) wrench.



Installation complete.